


Changing a standard image into a printable image


The Cricut® Image Library is full of images and fonts that can easily be turned into Print then Cut images. Using the Flatten tool makes this easier than ever—just the click of a button and you’re ready to Print then Cut!

Step 1: Select all the layers of the standard image you would like to Print then Cut.




Tip: In order for the Flatten tool to become active, you must have more than one layer selected. To change a single layer to a print, you must change the line type to a print from the Layer Attributes panel.

Step 2: At the top of the Layers panel, click “Flatten.”



Changing a standard image into a printable image

Step 3: The image now appears in the Layers panel as a single image and has a printer icon as the line type, indicating that it will Print then Cut. You will notice the black outlines of the image on the design screen have disappeared, also indicating it is a printable.



Tip: In order to make any edits to your flattened image, you will first need to unflatten the image using the tool in the Layers panel. This will open the Layer Attributes panel, allowing you to change the line type and color of each layer.